

# WIRING DIAGRAM FOR SINGLE BASSBAR™

**Directions:** Tie white/black & green wires together and solder to back of volume pot.  
Take orange wires (hot) and connect to pot lug where noted.  
Tape off white wire or connect to split switch depending on installation.

250K pots recommended for better tone.  
.022mfd cap recommended

## FOR FOLLOWING BASS PICKUPS

LACE BASSBAR

